

How to make Blowouts

Fukimodosinosato Manufacturing Company
http://www.fukimodosi.org/

Let's make them together!

Today,
I'll try to make
Blowouts
at the village of
Fukimodoshi!

Little Fuuko

First, take a close look
at the two materials.

•Paper for head part

(pouch-like paper,
to which a wire is attached one side.)



•Pipe

(paper tube, which is tipped with a
plastic mouthpiece.)



Pick up the
paper part,
the wire-attached
side facing.

the wire
It works as a return spring.

And then,
curl the paper
using On the table.

1cm

3cm

the paper 3 cm
from the right end and
1 cm from the left end.
Hold it firmly
in your fingers.

pull the right and
left ends of the paper,
it will curl up
neatly!

Place the wire
-attached side of
the paper
against the
middle point of
the needle
from underneath.
keep your hands
close to
each other.

Place it
at right
angle to
the needle.

90°

Pressing the paper
against the needle,
move your hands up
and down until your
right and left thumb
alternately touches
the needle. Repeat
this 2 or 3 times.

When your left hand
(which is holding the
point of 1 cm from the
end of the paper)
touches the needle,
loosen the pulling
strength of your
right hand.

loosen

1cm

Hook the left
end of the paper
on the needle,
and take your
left hand off
the paper.

release

Slowly move
your right hand
closer to the needle,
and the paper
will curl up.

curl

curl

The trick
is to make
the roll
tighter!

Take the curled paper
away from the needle,
and roll it
more tightly.



If the
mouthpiece
is hard to
insert,
blow
lightly
into
the paper.

It's easier to insert obliquely!

1

2

insert!

Insert
the untipped end
of the tube
about 1 cm into
the curled paper.

Tape the head
part and the tube
together.
Wrap the tape around
them, and the tape
should cover both
sides equally.
Tape firmly, in order
to prevent air leaks!

tape on!

When you pull the
tape off the tape
roll and to the
cutting blade of
the tape dispenser,
the length between
the roll and the
blade will be
about 5-6 cm.

Prepare
a 5-6 cm
long piece
of adhesive
tape.

The blowout won't recoil well
if played immediately after making

So, wait at least 15 minutes
until the head part becomes
properly curled into it's shape.